HITACHI
SERVICE MANUAL

TY	No. 559 E

TRK-720
[E, E(BS), W, W(UN), AU]

TN-21V-582 chassis



CONTENTS

SPECIFICATIONS 1
DISASSEMBLY 2
ADJUSTMENTS 3
INSPECTION OF MECHANISM 5
LUBRICATION 6
DIAL CORD SETTING 6
BLOCK DIAGRAM 7, 8
PRINTED WIRING BOARD 9
CIRCUIT DIAGRAM 11, 12, 13, 14
EXPLODED VIEW
Cabinet 15
Cassette chassis 16
REPLACEMENT PARTS LIST 17

SAFETY PRECAUTION

The following precautions should be observed when servicing.

1. Since many parts in the unit have special safety-related characteristics, always use genuine Hitachi replacement parts. Especially critical parts in the power circuit block should not be replaced with other makers. Critical parts are marked with ⚠ in the circuit diagram and printed wiring board.
2. Before returning a repaired unit to the customer, the service technician must thoroughly test the unit to ascertain that it is completely safe to operate without danger of electrical shock.

SPECIFICATIONS

● GENERAL SECTION

Semiconductors:	ICs: 5 Transistors: 2 [for E(BS), W, W(UN), AU] 3 [for E] Diodes: 7 [for E(BS), AU] 8 [for E, W, W(UN)] LEDs: 1 Varicap: 1
Power Supply:	AC: 220V, 50Hz [for E] AC: 240V, 50Hz [for E(BS), AU] AC: 110−127V/200−220V/230−250V, 50/60Hz [for W, W(UN)] DC: 12V [IEC R20 ("D" cell) x 8 or equivalent] Car: Use car battery adaptor (12V) [for W, W(UN)]
Power (Mains) Consumption:	18W
Power Output:	25W P.M.P. (AC operation) 3.5W/CH (10% T.H.D. DC operation)
Speakers:	12cm, 4ohms x 2 2cm, 300ohms x 2
Dimensions:	505(W) x 209(H) x 156(D) mm
Weight:	4.0kg (with batteries)

● TUNER SECTION

Circuit System:	FM/SW/MW/LW 4 bands superheterodyne [for E, E(BS)] FM/SW2/SW1/MW 4 bands superheterodyne [for W, W(UN), AU]
Tuning Range	FM: 87.5 to 108 MHz [for E, E(BS)] FM: 88 to 108 MHz [for W, W(UN), , AU] SW: 6 to 18 MHz [for E, E(BS)] SW2: 7 to 22 MHz [for W, W(UN), AU] SW1: 2.3 to 7 MHz [for W, W(UN), AU] MW: 530 to 1,605 kHz LW: 150 to 285 kHz [for E, E(BS)]
Sensitivity:	FM: 13 dB (pra.), 5 dB (max.) SW: 30 dB (pra.), 20 dB (max.) [for E, E(BS)] SW2: 30 dB (pra.), 24 dB (max.) [for W, W(UN), AU] SW1: 46 dB (pra.), 38 dB (max.) [for W, W(UN), AU] MW: 50 dB (pra.), 40 dB (max.) LW: 55 dB (pra.), 48 dB (max.) [for E, E(BS)]

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT.

RADIO CASSETTE TAPE RECORDER

May 1987 **TOYOKAWA WORKS**

Intermediate Frequency:	FM: 10.7 MHz SW/MW/LW: 465 kHz [for E, E(BS)] SW2/SW1/MW: 455 kHz [for W, W(UN), AU]
Antennas (Aerials):	FM/ SW/SW2: Rod antenna (aerial) SW1/MW/ LW: Ferrite antenna (aerial)

● TAPE RECORDER SECTION

Tape:	Cassette tape
Tape Speed:	4.75 cm/s
Recording System:	AC bias, 55 kHz
Erasing System:	Magnet
Frequency Response:	Normal: 60 to 10,000 Hz
S/N (Signal to Noise Ratio):	40 dB
Wow and Flutter:	0.25% (WRMS)
Crosstalk:	Between tracks: 60 dB Between channels: 30 dB
Erasing Ratio:	60 dB
Input sensitivity and impedance:	CD/Line in: 600mV, 60kohms
Output load impedance:	Headphones: 8 to 100ohms
Distortion:	3%
Motor:	DC micromotor
Head:	Permalloy

Specifications are subject to change without notice for performance improvement.

DISASSEMBLY

1. Removing cassette lid (Fig. 1)

Open the cassette lid, and pull out it to the front while applying a force in the direction of the arrow.



Fig. 1

2. Removing rear case (Fig. 2)

(1) Remove the battery lid.
(2) Remove 9 screws Ⓐ and remove the rear case.



Fig. 2

3. Removing main P.W.B. (Fig. 3)

(1) Remove the VOLUME and the TONE control knobs.
(2) Remove the FUNCTION and the BAND SELECTOR knobs, then remove the main P.W.B..



Fig. 3

4. Removing power supply P.W.B. (Fig. 4)

(1) Remove 2 screws Ⓑ.
(2) Remove the power supply P.W.B. from the rear case.



Fig. 4

5. Removing the cassette deck mechanism (Fig. 5)

Disengage 3 tabs Ⓒ and remove the cassette deck mechanism.

6. Removing speakers (Fig. 5)

(1) Remove 8 screws Ⓓ.
(2) Remove the speakers.



Fig. 5

ADJUSTMENTS

1. Radio Section

● Adjustment point [for W, W(UN), AU]



Fig. 6

AM Section for W, W(UN), AU (FM/SW2/SW1/MW 4bands)

Step		Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
			Measuring Instrument	Input Terminal	Output Terminal				
1	(1)	AM IF	● Genescope (455 kHz)	Ferrite antenna (Note 5)	TP3	455 kHz	Highest	T201 T203	Note 6
	(2)					Repeat step (1)			
2	(1)	SW2 OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	TP1 (thru SW dummy antenna) (Note 7)	TP3	6.7 MHz	Lowest	L154	Max.
	(2)					23 MHz	Highest	CT154	
	(3)					Repeat steps (1) and (2)			
3	(1)	SW2 ANT. (Tracking)				8 MHz	8 MHz	L151	Max.
	(2)					20 MHz	20 MHz	CT151	
	(3)					Repeat steps (1) and (2)			
4	(1)	SW1 OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	Ferrite antenna (Note 5)	TP3	2.2 MHz	Lowest	L155	Max.
	(2)					7.3 MHz	Highest	CT155	
	(3)					Repeat steps (1) and (2)			
5	(1)	SW1 ANT. (Tracking)				2.7 MHz	2.7 MHz	L152	Max.
	(2)					6.3 MHz	6.3 MHz	CT152	
	(3)					Repeat steps (1) and (2)			
6	(1)	MW OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	Ferrite antenna (Note 5)	TP3	515 kHz	Lowest	L156	Max.
	(2)					1650 kHz	Highest	CT156	
	(3)					Repeat steps (1) and (2)			
7	(1)	MW ANT. (Tracking)				600 kHz	600 kHz	L153	Max.
	(2)					1400 kHz	1400 kHz	CT153	
	(3)					Repeat steps (1) and (2)			

● Adjustment point [for E, E(BS)]



Fig. 7

AM Section for E, E(BS) (FM/SW/MW/LW 4bands)

Step		Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
			Measuring Instrument	Input Terminal	Output Terminal				
1	(1)	AM IF	● Genescope (465 kHz)	Ferrite antenna (Note 5)	TP3	465 kHz	Highest	T201 T203	Note 6
	(2)					Repeat step (1)			
2	(1)	SW OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	TP1 (thru SW dummy antenna) (Note 7)	TP3	5.8 MHz	Lowest	L154	Max.
	(2)					18.5 MHz	Highest	CT154	
	(3)					Repeat steps (1) and (2)			
3	(1)	SW ANT. (Tracking)				6.5 MHz	8 MHz	L151	Max.
	(2)					16 MHz	20 MHz	CT151	
	(3)					Repeat steps (1) and (2)			
4	(1)	MW OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	Ferrite antenna (Note 5)	TP3	515 kHz	Lowest	L155	Max.
	(2)					1650 kHz	Highest	CT155	
	(3)					Repeat steps (1) and (2)			
5	(1)	MW ANT. (Tracking)				600 kHz	2.7 MHz	L152	Max.
	(2)					1400 kHz	6.3 MHz	CT152	
	(3)					Repeat steps (1) and (2)			
6	(1)	LW OSC. (Covering)	● AM signal generator (400 Hz, 30% mod.) ● VTVM ● Oscilloscope	Ferrite antenna (Note 5)	TP3	145 kHz	Lowest	L156	Max.
	(2)					290 kHz	Highest	CT156	
	(3)					Repeat steps (1) and (2)			
7	(1)	LW ANT. (Tracking)				160 kHz	100 kHz	L153	Max.
	(2)					270 kHz	270 kHz	CT153 CT001	
	(3)					Repeat steps (1) and (2)			

FM Section *( ) : for E

Step		Adjustment Item	Measuring Instrument and Connection			Genescope or Signal Generator Frequency	Dial Pointer Position	Adjust	Reading
			Measuring Instrument	Input Terminal	Output Terminal				
1	(1)	FM IF	Turn T202 fully counterclockwise.						
	(1)	FM IF	● Genescope (10.7 MHz)	TP2	TP3	10.7 MHz	Highest	T101	Note 1
	(2)	S-Curve						T202	Note 2
2	(1)	FM OSC (Covering)	● FM signal generator (400 Hz, 30% dev.) ● Oscilloscope ● VTVM	TP1 (thru FM dummy antenna) (Note 3)	TP3	87MHz *(87.35 ± 0.15MHz)	Lowest	L102	Max.
	(2)					109MHz	Highest	CT102	
	(3)					Repeat steps (1) and (2).			
3	(1)	FM ANT. (Tracking)				90 MHz	90 MHz	L101	Max
	(2)					106 MHz	106 MHz	CT101	
	(3)					Repeat steps (1) and (2).			
4	(1)	FM MPX. (Multiplex)	● Frequency counter	Connect a 10μF 25V electrolytic capacitor between the No. 1 pin of IC301 and the ground.	TP5	—	—	RT301	38 kHz ±50 Hz (Note 4)

Note:

1. Feed in a weak signal to TP2 from the genescope. Adjust T101 for maximum gain and the waveform indicated in Fig. 8. If the center of the waveform cannot be lined up on the marker, adjust the right/left balance.

Adjust the genescope output so that there is a little noise riding on the leading edge.



Fig. 8

2. Use the T202 core to from the S-curve shown in Fig. 9. Adjust the symmetry of A and B about point C for linearity.



Fig. 9

3. FM dummy antenna shows Fig. 10 .



Rg: SG's output impedanc

Fig. 10

4. Connect the frequency counter to TP5 and connect a 330 kohms resistor parallel with the frequency counter.

5. Connect AM signal generator to loop antenna, bring near to ferrite antenna.

6. Feed in a weak signal from the genescope. Adjust T201, T203 for maximum gain and the waveform of Fig. 11.



Adjust the genescope output so that there is a little noise riding on the leading edge.

Fig. 11

7. SW dummy antenna shows Fig. 12.



Rg: SG's output impedance

Fig. 12

2. Tape Recorder Section

Perform the following adjustments in the sequence stated after cleaning the head, pressure roller, and capstan with a head cleaning stick moistened in alcohol.

Step	Adjustment Item	Measuring Instrument & Connection			Check Tape	Mode	Adjust	Reading
		Measuring Instrument	Input Terminal	Output Terminal				
1	Tape speed	● Frequency counter	—	Headphones Jack	Tape speed adjustment tape (3 kHz)	Playback	Semivariable resistor in the motor (Fig. 14)	3 kHz ± 20 Hz (Note 1)
2	Head azimuth	● VTVM	—	Headphones Jack	Head azimuth adjustment tape(10 kHz)	Playback	Azimuth adjusting screw	Output max. (Note 2)

Note:

1. Adjust within 30 sec. after heat-running for more than 20 minutes.

2. When the maximum values of both channels are different, adjust to the maximum value of the L channel. In this case, the difference between the maximum values of both channels should be within 2 dB.



Fig. 13



Fig. 14

INSPECTION OF MECHANISM

Item	Checking item		Reference value	Remarks
1	Pressure of pressure roller		300 – 500g	Note (Refer to page 6)
2	Take-up torque		30 – 60 g·cm	
3	Fast forward/Rewind torque		50 g·cm or more	
4	Auto-Stop sensor operation force		40 – 75 g	
5	Brake torque		15 g·cm or more	Measured in stop mode
6	Back tension torque	Take-up	1 – 6 g·cm	
		Supply	2 – 6 g·cm	
7	Flywheel thrust gap		0.05 – 0.5 mm	

Note:
Set this unit in the playback mode and press the pressure roller in the direction of the arrow using a fan type tension gauge, and measure the pressure when the pressure roller is released form the capstan.



Fig. 15

LUBRICATION

Lubricate one or two drops of oil to rotating point or lubricate grease to sliding point.
Lubricate the respective parts listed once every 1000 hours or once a year under normal conditions of use.
Avoid oiling them excessively, or rotation may become irregular because of oil splashes.

Lubrication point		Oil or Grease
Rotary section	Metal and metal	Pan motor oil (10W-40)
	Mold and metal	Sonic slider oil (# 1600)
Sliding section	Metal and metal	Hitasol (MO-138)
	Mold and mold Mold and metal	White grease (FL-LUBE-A)
Spring resonance prevention		Floil (GB-TS-1)

DIAL CORD SETTING

Stringing method

- String the dial cord to each rollers according to the order from ① to ⑧ after turned the pulley to the end of clockwise direction.
  Set the pointer to setting position.



Fig. 16

BLOCK DIAGRAM [for W, W(UN), AU]



BLOCK DIAGRAM [for E, E(BS)]



PRINTED WIRING BOARD

IC101	FM	AM
1	0.7V	5.5V
2	1.5V	5.2V
3	4.1V	5.2V
4	1.4V	5.2V
5	0V	5.5V
6	4.1V	5.2V
7	3.3V	5.1V
8	4.0V	5.2V
9	4.1V	5.2V

IC201	FM	AM		
1	0.7V	1.5V	9	1.4V	1.3V
2	0.7V	1.5V	10	4.8V	5.1V
3	1.8V	2.2V	11	4.8V	5.1V
4	2.3V	2.3V	12	1.4V	1.4V
5	0.8V	0.9V	13	1.4V	1.4V
6	0.8V	0.9V	14	1.4V	1.4V
7	0.7V	0.4V	15	1.4V	1.4V
8	0V	0V	16	4.8V	5.1V

IC301	FM	AM
1	2.7V	2.9V
2	3.4V	3.7V
3	4.8V	5.1V
4	4.0V	3.3V
5	0V	0V
6	4.2V	4.6V
7	4.1V	5.1V
8	2.3V	2.7V
9	2.3V	2.7V

IC401			
1	0V	8	0V
2	0V	9	1.3V
3	0V	10	1.3V
4	2.8V	11	2.8V
5	1.3V	12	0V
6	1.3V	13	5.5V
7	0V	14	5.5V

Q451	PLAY	REC
E	0V	0.1V
C	0V	5.1V
B	0V	0.8V

Q501	PLAY	REC
E	6.0V	6.0V
C	12.0V	11.8V
B	6.6V	6.6V

IC501			
1	0V	7	0V
2	6.0V	8	1.2V
3	11.7V	9	11.7V
4	11.9V	10	12.0V
5	1.2V	11	6.0V
6	0V	12	0V

ROD ANTENNA
SP. R ch
SP. L ch
PZT. SP.
PZT. SP.
BLACK
RED
BLUE
BROWN
RED
BLACK
MOTOR
C509
YELLOW
ORANGE
BROWN
RED
S001
LEAF SWITCH
R/P HEAD
WHITE
BROWN
LUG TERMINAL
WHITE
GRAY

MAIN P.W.B.

RV401L/R TONE CONTROL
RV402L/R VOLUME CONTROL
L153, CT153, CT001 [for E, E(BS)] LW ANT. ADJ.
L152, CT152 [for W, W(UN), AU] SW 1 ANT. ADJ.
L152, CT152 [for E, E(BS)] MW ANT. ADJ.
L153, CT153 [for W, W(UN), AU] MW ANT. ADJ.
L151, CT151 [for W, W(UN), AU] SW 2 ANT. ADJ.
L151, CT151 [for E, E(BS)] SW ANT. ADJ.
RT301 FM MPX ADJ.
L152 SW1 [for W, W(UN), AU]
L153 LW [for E, E(BS)]
L153 MW [for W, W(UN), AU]
L152 MW [for E, E(BS)]
L101, CT101 FM ANT. ADJ.
L102, CT102 FM OSC. ADJ.
FERRITE ANTENNA
PLAY
REC
IC401
IC301
IC201
IC101
Q451
Q501
S201
S401
S403
S402 FUNCTION SWITCH
Tape
Radio
CD/Lin
FUNCTION
S201 BAND SELECT SWITCH
S401 REC PLAY SELECT SWITCH
S403 FM MODE SELECT RIF SWITCH
T101 FM IF ADJ.
T202 S-Curve ADJ.
T201, T203 AM IF ADJ.
L156, CT156 [for W, W(UN), AU] MW OSC. ADJ.
L155, CT155 [for W, W(UN), AU] SW 1 OSC. ADJ.
L154, CT154 [for W, W(UN),AU] SW 2 OSC. ADJ.
L155, CT155 [for E, E(BS)] MW OSC. ADJ.
L156, CT156 [for E, E(BS)] LW OSC. ADJ.
L154, CT154 [for E, E(BS)] SW OSC. ADJ.
THE CIRCUIT SYMBOL (☆) MEANS DIFFERENCE FOR DESTINATION. (REFER TO THE TABLE IN THE DROWING.)

	E	E(BS)	W/W(UN)	AU
Q151	USE	–	–	–
D102	USE	–	–	–
D605	–	–	USE	–
C151	USE	USE	–	–
C153	–	–	USE	USE
C161	USE	–	–	–
C173	USE	USE	–	–
C176	USE	USE	–	–
R154	USE	USE	–	–
R161	USE	–	–	–
R162	USE	–	–	–
J601	–	–	USE	–
S602	–	–	USE	–
CT154, 155, 156	◎	◎	◎	◎
Jumper 001	–	USE	USE	USE
Jumper 002	USE	USE	–	–
Jumper 69	USE	USE	–	USE
Jumper 70	USE	USE	–	USE
SPACER	–	–	USE	–

POWER SUPPLY P.W.B.

POWER SUPPLY CORD
S601 AC BATT SELECT SWITCH
AC ↔ BATT
BATT. SPRING
BATT. TERMINAL
P001
2P TERMINAL
Jumper 69
S602 ☆ SPACER
POWER TRANS.
PT
J601
Jumper 70
F601
BLUE
BROWN
VIOLET
BLACK
RED
WHITE

JACK P.W.B.

J501
PL502
R504L
R504R

MIC P.W.B.

MIC

LED P.W.B.

LED1
D603

AN7312	14 ~ 8 / 1 ~ 7
TA7343AP TA7358P	1 ~ 9
TA7640AP	16 ~ 9 / 1 ~ 8
μPC1278H	1 ~ 12
2SC1684R	E C B
2SD1226(P)	B C E
HIT9011GH	E C B
1N4001 HZ-7A-1	K A
1N4148 1N4148T 1S2790	K A

CIRCUIT DIAGRAM [for W, W(UN), AU]



CIRCUIT DIAGRAM [for W, W(UN), AU]



CIRCUIT DIAGRAM [for E, E(BS)]



CIRCUIT DIAGRAM [for E, E(BS)]

The circuit symbol (☆) means difference for destination. (Refer to the table in the drowing)


FM MODE SELECT SWITCH
IC201 TA7640AP AM/FM MIX AM/FM IF
AM IF ADJ.
FM IF ADJ.
IC301 TA7343AP FM MPX
LED PWB.
FM MPX ADJ.
BAND SELECT SWITCH
IC101 TA7358P FM RF AMP FM OSC MIXER
FM OSC. ADJ.
SW OSC. ADJ.
MW OSC ADJ.
LW OSC. ADJ.
SW ANT. ADJ.
MW ANT. ADJ.
LW ANT. ADJ.
Q151 HIT9011GH SW LOR
MAIN P.W.B.(Radio section)
ROD ANTENNA
CAUTION
Use the electrolytic capacitors with explosion-proof valve when the diameter of them is more than 10mm/.
Voltage FM / AM MODE
(for Audio Section)

EXPLODED VIEW (Cabinet)

● Nos. are reference Nos. of parts list.



EXPLODED VIEW (Cassette chassis)

● Nos. are reference Nos. of parts list.



CD : Ceramic discal
EL : Electrolytic
MF : Mylar film
ST : Styrol
CF : Carbon film
MO : Metal oxide
FR : Fuse resister

REPLACEMENT PARTS LIST

SYMBOL No.	PART No.	DESCRIPTION
		CAPACITORS
C101	0208664	CD 15PF ±5% 50V [for W, W(UN), AU]
	0208666	CD 18PF ±5% 50V [for E, E(BS)]
C102	02441012	CD 1000PF ±10% 50V
C103	0248669	CD 24PF ±0.5% 50V [for W, W(UN), AU]
	02486682	CD 22PF ±0.5% 50V [for E, E(BS)]
C105	02486462	CD 6PF ±0.5PF 50V
C106	02441012	CD 1000PF ±10% 50V
C107	0248341	CD 30PF ±5% 50V [for W, W(UN), AU]
	0248334	CD 15PF ±5% 50V [for E, E(BS)]
C109	02464482	CD 22PF ±0.5% 50V
C110	0248016	CD 6PF ±0.5PF 50V
C111	02097312	CD 1000PF ±10% 50V
C112	02441012	CD 1000PF ±10% 50V
C113	02086842	CD 100PF ±5% 50V
C151	0208664	CD 15PF ±5% 50V [for E]
	0208633	CD 3PF ±0.25PF 50V [for E(BS)]
C152	0208634	CD 4PF ±0.25PF 50V [for W, W(UN), AU]
	0208646	CD 6PF ±0.5PF 50V [for E, E(BS)]
C153	0208634	CD 4PF ±0.25PF 50V [for W, W(UN), AU]
C154	0208664	CD 15PF ±5% 50V [for W, W(UN), AU]
	02086682	CD 22PF ±5% 50V [for E, E(BS)]
C155	0208662	CD 12PF ±5% 50V [for W, W(UN), AU]
	02086682	CD 22PF ±5% 50V [for E, E(BS)]
C156	0208666	CD 18PF ±0.5PF 50V [for W, W(UN), AU]
	0208648	CD 8PF ±0.5PF 50V [for E, E(BS)]
C157	02750112	MF 0.01 μF ±10% 50V
C158	1221396	ST 1500PF ±5% 50V
C159	1221393	ST 360PF ±5% 50V
C161	02441712	CD 0.01 μF +80% −20% 50V [for E]
C162	02441712	CD 0.01 μF +80% −20% 50V
C163	02441732	CD 0.022 μF +80% −20% 50V
C171	02486352	CD 5PF ±0.25PF 50V
C173	0208680	CD 68PF ±5% 50V [for E, E (BS)]
C176	0208686	CD 120PF ±5% 50V [for E, E (BS)]
C177	02497662	CD 0.068 μF ±20% 25V
C178	0252521	EL 10 μF ±20% 16V
C204	02441712	CD 0.01 μF +80% −20% 50V
C205	02441712	CD 0.01 μF +80% −20% 50V
C206	02441732	CD 0.022 μF +80% −20% 50V
C207	02441732	CD 0.022 μF +80% −20% 50V
C208	02523222	EL 22 μF ±20% 10V
C209	02097232	CD 470PF ±10% 50V
C210	02528052	EL 0.47 μF ±20% 50V
C211	02091752	CD 0.047 μF +80% −20% 50V
C212	02528132	EL 3.3 μF ±20% 50V
C213	02091752	CD 0.047 μF +80% −20% 50V
C214	02522322	EL 220 μF ±20% 6.3V
C301	02528112	EL 1 μF ±20% 50V
C302	02528132	EL 3.3 μF ±20% 50V
C303	1221395	ST 1000PF ±5% 50V
C304	02528112	EL 1 μF ±20% 50V
C305LR	0209736	CD 6800PF ±10% 50V
C306LR	0252801	EL 0.1 μF ±20% 50V
C307	02522322	EL 220 μF ±20% 6.3V
C308L	02097352	CD 4700PF ±10% 50V [for W, W (UN), AU]
C308R	02441092	CD 4700PF ±10% 50V [for W, W (UN), AU]
C308LR	02097352	CD 4700PF ±10% 50V [for E, E (BS)]
C309	02441072	CD 3300PF ±10% 50V
C401	02441752	CD 0.047 μF +80% −20% 50V
C402LR	02086882	CD 150PF ±5% 50V
C403LR	02097322	CD 1500PF ±10% 50V
C404LR	02523312	EL 100 μF ±20% 10V
C405LR	0252521	EL 10 μF ±20% 16V
C407LR	02750152	MF 0.047 μF ±10% 50V
C408	0252521	EL 10 μF ±20% 16V
C410LR	02097332	CD 2200PF ±10% 50V
C411LR	02740132	MF 2200PF ±10% 50V
C412LR	02497642	CD 0.033 μF ±20% 50V
C413LR	0252802	EL 0.22 μF ±20% 50V
C414	02522322	EL 220 μF ±20% 6.3V
C415L	02441112	CD 6800PF ±10% 50V
C415R	02097362	CD 6800PF ±10% 50V
C416LR	02441012	CD 1000PF ±10% 50V
C417LR	02486962	CD 330PF ±5% 50V [for W, W (UN), AU]
C417L	02486962	CD 330PF ±5% 50V [for E, E (BS)]
C417R	0209721	CD 330PF ±10% 50V [for E, E (BS)]
C418	02441712	CD 0.01 μF +80% −20% 50V
C419LR	02528112	EL 1 μF ±20% 50V
C421LR	02486962	CD 330PF ±5% 50V
C451	02523312	EL 100 μF ±20% 10V
C452	02097312	CD 1000PF ±10% 50V
C453	02750152	MF 0.047 μF ±10% 50V
C454	02486862	CD 120PF ±5% 50V
C501LR	02097312	CD 1000PF ±10% 50V
C502LR	0252521	EL 10 μF ±20% 16V
C503	0252532	EL 220 μf ±20% 16V [for AU]
	02526322	EL 220 μF ±20% 25V [for W, W (UN), E, E (BS)]
C504LR	02760112	MF 0.1 μF ±10% 50V
C505LR	02523312	EL 100 μF ±20% 10V
C506LR	02523352	EL 470 μF ±20% 10V
C507	02523252	EL 47 μF ±20% 10V
C508	0252541	EL 1000 μF ±20% 16V [for AU, E, E (BS)]
C508	0252642	EL 2200 μF ±20% 25V [for W, W (UN)]
C509	02526222	EL 22 μF ±20% 25V
C601	02441712	CD 0.01 μF +80% −20% 50V
C602	02441712	CD 0.01 μF +80% −20% 50V
C603	02441712	CD 0.01 μF +80% −20% 50V
C604	02441712	CD 0.01 μF +80% −20% 50V
		RESISTORS
R101	01703342	CF 33Ω ±5% SRD1/8P
R102	0113575	CF 22Ω ±5% SRD1/6P
R154	0113647	CF 22KΩ ±5% SRD1/6P [for E, E (BS)]
R155	0113643	CF 15KΩ ±5% SRD1/6P
R156	0113621	CF 1.8KΩ ±5% SRD1/6P [for W, W (UN), AU]
	0113623	CF 2.2KΩ ±5% SRD1/6P [for E, E (BS)]
R161	0113591	CF 100Ω ±5% SRD1/6P [for E]
R162	0113675	CF 330KΩ ±5% SRD1/6P [for E]
R201	0113663	CF 100KΩ ±5% SRD1/6P
R202	0113639	CF 10KΩ ±5% SRD1/6P
R203	0113597	CF 180Ω ±5% SRD1/6P
R207	0113643	CF 15KΩ ±5% SRD1/6P
R208	0113583	CF 47Ω ±5% SRD1/6P
R209	0113663	CF 100KΩ ±5% SRD1/6P
R301	0113615	CF 1KΩ ±5% SRD1/6P
R302	0113639	CF 10KΩ ±5% SRD1/6P
R303	01703492	CF 560Ω ±5% SRD1/8P
R304	0113671	CF 220KΩ ±5% SRD1/6P
R305LR	0113627	CF 3.3KΩ ±5% SRD1/6P
R307LR	0113631	CF 4.7KΩ ±5% SRD1/6P
R308	01129122	MO 47Ω ±10% RS1B
R401	0113627	CF 3.3KΩ ±5% SRD1/6P
R402	0113615	CF 1KΩ ±5% SRD1/6P
R403	0113611	CF 680Ω ±5% SRD1/6P
R404LR	0113679	CF 470KΩ ±5% SRD1/6P
R405LR	0113609	CF 560Ω ±5% SRD1/6P
R407L	0113655	CF 47KΩ ±5% SRD1/6P
R407R	01703722	CF 47KΩ ±5% SRD1/8P
R408LR	0113609	CF 560Ω ±5% SRD1/6P
R409LR	0113567	CF 10Ω ±5% SRD1/6P
R411LR	0113639	CF 10KΩ ±5% SRD1/6P
R412LR	0113629	CF 3.9KΩ ±5% SRD1/6P
R413LR	0113659	CF 68KΩ ±5% SRD1/6P
R414LR	0113645	CF 18KΩ ±5% SRD1/6P
R415LR	0113639	CF 10KΩ ±5% SRD1/6P
R416LR	0113631	CF 4.7KΩ ±5% SRD1/6P
R417LR	0113625	CF 2.7KΩ ±5% SRD1/6P
R418	0129561	CF 100Ω ±5% SRD1/4P
R419LR	0113659	CF 68KΩ ±5% SRD1/6P
R420LR	0113631	CF 4.7KΩ ±5% SRD1/6P
R421LR	0113663	CF 100KΩ ±5% SRD1/6P
R422LR	0113645	CF 18KΩ ±5% SRD1/6P
R451	0112915	MO 33Ω ±10% RS1B
R452	0113561	CF 5.6Ω ±5% SRD1/6P
R453	0113655	CF 47KΩ ±5% SRD1/6P
⚠FR501	1118447	FR 6.8Ω ±5% RN1/4B
R501LR	0113615	CF 1KΩ ±5% SRD1/6P
R503LR	0113551	CF 2.2Ω ±5% SRD1/6P

SYMBOL No.	PART No.	DESCRIPTION
R504LR	01703382	CF 68Ω ±5% SRD1/8P
R505	0113611	CF 680Ω ±5% SRD1/6P
		ICs & TRANSISTORS
IC101	2398201	TA7358P
IC201	2389511	TA7640AP
IC301	2301041	TA7343AP
IC401	2300881	AN7312
IC501	2389521	μPC1278H
Q151	2319083	HIT9011GH [for E]
Q451	2319101	2SC1684R
Q501	2317803	2SD1266(P)
		DIODES
D101	2398082	IN4148T
D102	2398081	IN4148 [for E]
D103	2338031	1S2790
D501	2398081	IN4148
D601	2398062	IN4001
D602	2398062	IN4001
D603	2398062	IN4001
D604	2398062	IN4001
D605	2398062	IN4001 [for W, W (UN)]
ZD501	2337541	HZ-7A-1
LED1	2397753	LN217RP
		VARIABLE RESISTORS
RT301	0189331	5kΩ (FM MPX ADJ.)
RV401LR	0166932	10kΩ-(A) (TONE CONTROL)
RV402LR	0166944	10kΩ-(B) (VOLUME CONTROL)
		COILS&TRANSFORMERS
L101	2137683	FM RF coil
L102	2137687	Choke coil
L151	2137662	SW ANT coil [for E, E (BS)]
	2137821	SW ANT coil [for W, W (UN), AU]
	2757994	Ferrite antenna (L152, L153) [for E, E (BS)]
	2757982	Ferrite antenna (L152, L153) [for W, W (UN), AU]
L154	2137671	SW OSC coil [for E, E (BS)]
	2137672	SW OSC coil [for W, W (UN), AU]
L155	2137631	MW OSC coil [for E, E (BS)]
	2137633	SW OSC coil [for W, W (UN), AU]
L156	2137642	LW OSC coil [for E, E (BS)]
	2137631	MW OSC coil [for W, W (UN), AU]
L171	2137684	Choke coil
L501	2227748	Choke coil
T101	2135651	FM IF transformer
T201	2154952	AM IF transformer
T202	2154964	FM IF transformer
T203	2154951	AM IF transformer
T401	2136891	REC OSC transformer
		MISCELLANEOUS
J401LR	2678781	2P pin jack
J501	2678234	Headphones jack
⚠J601	2678282	DC jack [for W, W (UN)]
⚠P001	2689461	2P terminal
PVC	0282182	Capacitor variable (CT101, CT102, CT150, CV101, CV102, CV151, CV152)
CT151-153	0283130	Capacitor semi variable
CT154-156	0283130	Capacitor semi variable [for W, W (UN), AU]
CT154, 155	0283557	Capacitor semi variable [for E, E (BS)]
CT156	0282148	Capacitor semi variable [for E, E (BS)]
BPF1	2137191	FM band pass filter
CF201	2135321	Ceramic filter
S201	2629282	Slide switch (BAND SELECT)
S401	2629293	Slide switch (REC/PLAY SELECT)
S402	2628581	Slide switch (FUNCTION)
S403	2629331	Slide switch (FM MODE SELECT)
⚠S601	2629261	Slide switch (AC/BATT. SELECT)
⚠S602	2618472	Switch (VOLTAGE SELECT) [for W, W (UN)]
⚠F601	2728073	Fuse T1.25A
	2737441	Mic.
	8691406	BT bind head screw (3φ x 6) (IC 501)
	86914082	BT bind head screw (3φ x 8) (Q 501)
		CABINET
1	3303331	Tuning knob (BLACK) [for W, W(UN), AU]
	3303333	Tuning knob (SILVER) [for W, W(UN), AU]
	3303183	Tuning knob (BLACK) [for E, E(BS)]
2	3303091	Fine knob (BLACK) [for W, W(UN), AU]
	3303094	Fine knob (SILVER) [for W, W(UN), AU]
3	3348613	Gear [for W, W(UN), AU]
4	3801491	28φ knob (BLACK) [for W, W(UN), AU, E, E(BS)]
	3801493	28φ knob (SILVER) [for W, W(UN), AU]
5	3801771	Handle
6	3801461	Handle arm
7	4577832	BT flat head screw (3φ x 10) (handle)
8	4577818	Bind tapping screw (3φ x 50) (rear case)
9	4042921	Front case assy (BLACK) [for W, W(UN), AU]
	4042922	Front case assy (SILVER) [for W, W(UN), AU]
	4042923	Front case assy (BLACK) [for E, E(BS)]
10	3801582	Cassette lid
11	3934271	Roller
12	4577661	Roller pin
13	3801531	Function lever (BLACK) [for W, W(UN), AU, E, E(BS)]
	3801532	Function lever (SILVER) [for W, W(UN), AU]
14	3801541	Band lever (BLACK) [for W, W(UN), AU, E, E(BS)]
	3801542	Band lever (SILVER) [for W, W(UN), AU]
15	3801551	Pointer
16	4594824	Tuning shaft
17	3801761	100φ pulley
18	3340321	Spring
19	3801501	Select knob
20	3970221	Gear damper
21	3801591	Speaker grille
22	3368265	Lid spring
23	2403841	12cm speaker
24	2403353	Piezo tweeter
25	4418013	E ring
26	86914102	BT bind head screw (3φ x 10) (gear damper, pulley holder)
27	4578972	BT flange screw (3φ x 10) (12cm speaker)
28	4042941	Rear case assy (BLACK) [for W]
	4042942	Rear case assy (BLACK) [for W(UN)]

SYMBOL No.	PART No.	DESCRIPTION
28	4042943	Rear case assy (BLACK) [for AU]
	4042945	Rear case assy (SILVER) [for W]
	4042946	Rear case assy (SILVER) [for W(UN)]
	4042947	Rear case assy (SILVER) [for AU]
	4042948	Rear case assy (BLACK) [for E, E(BS)]
29	3973501	Battery lid
30	3369781	Bat. spring
31	2758231	Rod antenna
32	87444122	Bind head screw (3 ϕ x 12) (rod antenna)
33	4578976	BT bind head screw (3 ϕ x 20) (power transformer)
34	2588831	TN-21-582 mechanism assy
35	3801481	Cassette button (BLACK) [for W, W(UN), AU, E, E(BS)]
	3801483	Cassette button (SILVER) [for W, W(UN), AU]
36	4468611	Record plate
37	88151132	Lock washer
38	4578281	Screw (2.6 ϕ x 4) (record plate)
⚠39	2706584	Power supply cord [for W, W(UN)]
⚠	2706251	Power supply cord [for AU]
⚠	2707709	Power supply cord [for E]
⚠	2717902	Power supply cord [for E(BS)]
⚠40	2249604	Power transformer [for W, W(UN)]
⚠	2249602	Power transformer [for AU, E(BS)]
⚠	2249601	Power transformer [for E]
for ACCESSORIES		
⚠	2667922	Siemens plug
CASSETTE CHASSIS		
1	4818991	Main base assy
2	4818992	Switch plate
3	4832411	Push button actuator assy
4	4820212	REC button lever
5	4820213	PLAY button lever
6	4818996	RWD button lever
7	4818997	FF button lever
8	4818998	STOP button lever
9	4818999	PAUSE button lever assy
10	4818990	RWD lever
11	4819131	PAUSE lever
12	4819132	PAUSE lever spring
13	4819133	PAUSE stopper
14	4820214	Button lever spring
15	4820215	Sub chassis
16	4819007	Button lever spring
17	4819100	Button lever spring
19	4819008	Actuator spring
20	4819009	Auto lever

SYMBOL No.	PART No.	DESCRIPTION
21	4819000	Auto lever spring
22	4820217	PLAY button lever spring
23	2789801	Leaf switch
25	4820218	Switch actuator spring
26	4820219	Head panel
27	4819014	Head base
28	4832412	Sensing plate assy
29	4820221	Head panel spring
30	4819018	MG arm
31	4819006	PR stopper
32	4819045	Screw
33	4819017	Spring
34	4820222	Pressure roller arm assy
35	4820223	Pressure roller arm spring
36	4832413	RF pulley arm
37	4820225	RF pulley arm spring
38	4832414	RF collar arm screw
39	4820227	Belt
40	4820231	Flywheel assy
41	4819575	Reel P.W.B. assy
42	4832415	Take up gear plate assy
43	4832416	Take up roller gear
44	4819020	TG plate spring
45	4832417	FF gear
46	4819037	Spring
47	4819033	Supply reel assy
48	4819034	Take up reel assy
49	4819035	Record safety lever
50	4819032	Spring
52	4819039	Motor rubber
53	4819533	Motor collar screw
54	4820235	Main belt
55	4819043	Eject slide lever
56	4819044	Eject slide lever spring
57	4820242	Pack spring
58	2557321	Erase head
59	2555671	Record playback head
60	4819063	Tapping screw (2 ϕ x 3)
61	4819068	Tapping screw (2 ϕ x 4)
62	4819607	Bind tapping screw (2 ϕ x 5)
63	4819069	Screw (2 ϕ x 6)
64	4819060	Screw (2 ϕ x 7)
65	4819600	Azimuth screw
67	4819077	Washer (1.2 ϕ x 3 x 0.4)
68	4819078	Washer (1.55 ϕ x 3.8 x 0.5)
69	4832432	Washer (2.05 ϕ x 4 x 0.5)
71	4820366	Motor assy
72	4820241	Mat
73	4819062	Lug

HITACHI SALES EUROPA GmbH
Rungedamm 2,2050 Hamburg 80,
West Germany
Tel. 040-734 11-0

HITACHI SALES (U.K.) Ltd.
Hitachi House, Station Road, Hayes, Middlesex UB3 4DR, England
Tel. 01-848-8787

HITACHI SALES SCANDINAVIA AB
Rissneleden 8, Box 7138, 172-07 Sundbyberg, Sweden
Tel. 08-98 52 80

HITACHI SALES NORWAY A/S
P.O. Box 503, Oerebekk, 1620,
Gressvik, Norway
Tel. 032-28255

SUOMEN HITACHI OY
Takojankatsu 5, 15800 Lahti 80, Finland
Tel. (918) 44 241

HITACHI SALES A/S
Kuldyssen 13, DK-2630, Taastrup, Denmark
Tel. 02-999200

HITACHI SALES A.G.
Bahnhofstrasse, 19, 5600 Lenzburg, Switzerland
Tel. 064-513621

HITACHI SALES WARENHANDELS GMBH
A-1180/Wien, Kreuzgasse 27, Austria
Tel. 0222-421670

HITACHI SALES ITALIANA, S.P.A.
Via Cristoford Colombo 49, Trezzano sul naviglio (Milano), Italy
Tel. 44 59 031

HITACHI SALES BELGIUM S.A./N.V.
Chaussee de Namur, 56, B-1400 Nivelles, Belgium
Tel. (3267) 21-71-81, (3267) 21-79-81

HITACHI SALES IBERICA, S.A.
Gran Via Carlos Tercero, 101, 1-1, Barcelona-08028, Spain
Tel. 330-8652

HITACHI PRODUCTIONS MAROC ELECTRONIQUES DOMESTIQUES S.A.
Rue du Havre, Casablanca, Morocco
Tel. 30-73-68, 30-73-57

HITACHI CANARIAS S.A.
Calle San-Francisco No. 19, 38002, Santa Cruz de Tenerife Canary Islands
Tel. 24-64-98

HITACHI SALES (HELLAS) S.A.
110 Syngrou St., Athens, Greece
Tel. 9219082, 9233469

HITACHI SALES (MALAYSIA) SDN, BHD.
Wisma Hitachi. No. 2. Lorong 13/6A, 46200 Petaling Jaya. Malaysia
Tel. 7573455

HITACHI (SINGAPORE) PTE., LTD.
18 Pasir Panjang Road # 01-03 PSA Multi-Storey Complex. Singapore 0511
Tel. 2738102

HITACHI SALES (THAILAND) LTD.
2240-46, New Petchburi Road, Bangkapi, Hueykuang
Bangkok, Thailand
Tel. 314-2741

HITACHI ELECTRIC SERVICE CO., (HONG KONG) LTD.
4th Floor Leun Tai Industrial Bldg., 72-76 Kwai Cheong Road Kwai Chung N.T., Hong Kong
Tel. 0-242976, 0-240126

HITACHI SALES AUSTRALIA PTY LTD.
153 Keys Road, Moorabbin, Victoria 3189 Australia
Tel. 555-8722

HITACHI SALES CORPORATION OF AMERICA
Eastern Regional Office
1290 Wall Street West, Lyndhurst, New Jersey 07071, U.S.A.
Tel. 201-935-8980

Mid-Western Regional Office
1400 Morse Ave., Elk Grove Village, Illinois 60007, U.S.A.
Tel. 312-593-1550

Southern Regional Office
510 Plaza Drive, College Park, Georgia 30349, U.S.A.
Tel. 404-763-0360

Headquaters Western Regional Office
401 West Artesia Boulevard, Compton, California 90220 U.S.A.
Tel. 213-537-8383

HITACHI SALES CORPORATION OF HAWAII. INC.
3219 Koapaka Street. Honolulu, Hawaii 96819, U.S.A.
Tel. 808-836-3621

HITACHI (HSC) CANADA INC.
3300 Trans-Canada Highway, Pointe Claire, Quebec, H9R 1B1, Canada
Tel. 514-697-9150

Hitachi Sales Centroamericana, S.A.
HITACHI ELECTRONICA CENTROAMERICANA S.A.
San Rafael de Escazu, (Apartado 10272), San Jose, Costa Rica
Tel. 28-20-11, 28-00-37

Hitachi Sales Corporation de Panama, S.A.
INTERNATIONAL HITACHI SALES PANAMA, LTD.
PRODUCTOS HITACHI, S.A.
Apartado 7657 Panama 5 Panama City, Rep. of Panama
Tel. 61-3100, 61-4305

HITACHI-FRANCE (RADIO-T.V. ELECTRO-MENAGER) S.A.
95-101 Rue Charles Michels,
93200 SAINT-DENIS,
France
Tel. 4821 6015

HITACHI LTD. TOKYO JAPAN
Head Office: THE HITACHI ATAGO BLDG.
No. 15-12, 2-Chome Nishi-Shinbashi
Minato-ku, Tokyo 105, Japan
Tel. Tokyo (03) 502-2111

TRK-720 TY No. 559 E

Printed in Japan (Ho)